


ALL-ALUMINUM Installation Guide

In Your Kit

Gutter Guard
(Also referred to as Guard)



Recommended Additional Tools

GLOVES DRILL TAPE MEASURE
SAFETY GLASSES TIN SNIPS OR DREMEL EXTENSION LADDER

Safety Is Our #1 Priority.

During installation we recommend that you...

- Wear gloves and safety glasses.
- Use an extension ladder and standoff for stability.
- Make all cuts to the gutter guards on the ground.

ALSO MAKE SURE TO:

- Obey local building codes.
- Remove any labels/stickers from the gutter guard piece as needed.


FREEZING CONDITIONS

If you live in an area that is prone to freezing, the following issues can occur with any gutter guard: Icicles/Dams forming and Snow Melting.


Important Reminder

Missing this step can result in **rainwater runoff**.


Back wing should be facing up for correct installation.



1 Clean Out & Repair Gutters




2 Measure & Cut the Guard as Needed



Use a new, or freshly sharpened pair of tin snips or a dremel to cut through the guard as needed. Not every piece of guard needs to be trimmed, only make cuts to end pieces to fit the length of the gutter. For safety, use protective gloves and make cuts while on the ground.


3 Start Laying the First Piece

We recommend starting at the end of the gutter.



Drop the guard into the gutter with the front edge of the gutter guard resting on the front lip of the gutter. The guard is designed to rest on the gutter braces/brackets with a gradual upwards slope towards the house.

4 Securing the Guard




Using the provided 1/2 inch screws, secure the front edge of the guard to the gutter at both ends using the pre-drilled screw holes (3 inches from each end). Use 2 additional screws to fasten the front edge of the guard to the gutter.


Next, secure the back wing of the guard in place using the same screw pattern as used on the front edge. *Note: 1 inch screws may be necessary here if you have difficulty securing with the provided 1/2 inch screws.*

5 Continue Installing Next Piece

Overlapping pieces should create a seamless finish.



Slightly overlap the next guard so the perforated holes align with the previous piece. Follow the same screw pattern as the previous piece.




COMPLETING The Job


- 1 Clean up the jobsite.
 - 2 Help your customer register their warranty at leafblaster.com/register-aluminum.
 - 3 Ask for a great review and a referral!
- A JOB DONE RIGHT

How-To Install: Inside and Outside Corners


HOW-TO Inside Corners



Trim the front edge of Piece A as shown in Image 1. Use the drain holes in the trough as a cut line. This will allow Piece B to fit properly atop Piece A.




Cut the end of Piece B at 45 degrees. Next, notch the edge of the back wing in a 1/2 inch straight line. Place Piece B atop Piece A and check that the alignment has no gapping.




A completed inside corner should look like Image 3. Piece B should rest atop Piece A creating a seamless miter. For a tighter seal, place a screw through Piece B into Piece A to pull the pieces together.

Note: The drainage holes will not align where the pieces overlap at the corners. This is common. Water will drain from the top piece to the bottom piece without issue.


HOW-TO Outside Corners



Cut the end of Piece A at 45-degrees. Next, cut a 1/2 inch wide notch from the back wing. Then, trim off 3/4 to 1 inch from the front edge in a straight line.



Cut the end of adjoining Piece B at 45-degrees. Repeat the 1/2 inch wide notch cut on the back wing and the 3/4 to 1 inch trim from the front edge. Pieces A & B should slightly overlap.



A completed outside corner should look like Image 3. For a tighter seal, place a screw through Piece B into Piece A to pull the pieces together.

Note: The drainage holes will not align where the pieces overlap at the corners. This is common. Water will drain from the top piece to the bottom piece without issue.